


huperRemote gViewer Quick Guide

huperRemote gViewer supports online video surveillance for Android mobile phones. Remote users can easily operate huperLab video surveillance systems, like video camera monitoring, and PTZ camera control as on the computer. The functions that huperRemote gViewer offers include single/4 split screen view switch, one touch snapshot, on-screen PTZ control, and full screen view.


Installing huperRemote gViewer

Please follow the steps below to install huperRemote gViewer:


- Enter the Settings of Android mobile device and select “Application.”




- Check the option “Unknown sources.”




- Open the browser screen, and type the URL address <http://211.23.2.67/gviewer.apk>. Then touch GO to begin to download file.




- When the file is downloaded completely, select “gviewer.apk,” and then touch “Install” to continue.





- When the file is installed completely, touch “Open” to start huperRemote gViewer program or touch “Done” to end installation process.




Starting huperRemote gViewer

Enter the main screen of your Android mobile device, and then touch  to launch the gViewer program.




Touch the  button on the main screen to connect demo remote site.



When you rotate Android mobile device, huperRemote gViewer will turn to be full screen display horizontally.

■ huperRemote gViewer UI (Vertical)




■ huperRemote gViewer UI (Horizontal)






Using huperRemote gViewer

The main functions of huperRemote gViewer are listed below. Please check the following sections for details.








Link Status

-  Offline Status, touch it to go online according to your link settings.
-  Connecting Status
-  Online Status, touch it to go offline


Camera Switch



The icon shows linked camera status and cameras available to switch. Every camera icon works as respective button for user to switch. The following icons show different status of camera connection:

-  Disable
-  Normal
-  Normal with event indicator
-  Down
-  Down with event indicator


Another way to quickly switch channel under single split or full screen mode is to slide user's finger to the left to view next channel, or to the right to view the previous one. The operation method is shown as below:



Function Buttons



The following function buttons work as below:



Single split switch



4 split switch



Snapshot



PTZ control



Link settings

Full Screen Display

With connection to the surveillance site, the display will turn into horizontal full screen display (single split only) while rotating the Android mobile device 90-degree. The display is as below:



- ❖ The display will return to original UI screen while rotating the Android mobile device back,.

PTZ Control Mode

Under PTZ Control Mode, there appears related control buttons for PTZ operation in video preview screen. All control buttons are as below:




(Full Screen Display)


Exit Program

Touch the back button of Android mobile device to close huperRemote gViewer program.

Link Settings




Touch  to show list screen of link settings.




To add new link settings, follow the steps below:

- Unselect any item in the list and touch Edit button.



- Touch Add button to add new settings.



To modify current link settings, follow the steps below:

- Select item in the list and touch Edit button to modify current settings.



Copyright

© 2010 Huper Laboratories CO., LTD. All rights reserved.

The trademarks mentioned in the manual are legally registered to their respective companies.

Notice

The written content provided with this product is the property of huperLab.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without huperLab's prior written permission. Specifications and features are subject to change without prior notice.

For more product details, please click onto huperLab's website at www.huperlab.com